



**USER MANUAL UMAX031600**

Version 1.0.1

# **2 LED OUTPUTS CAN CONTROLLER SAE J1939**

## **USER MANUAL**

**P/N: AX031600**

## Table of Contents

<b>1. OVERVIEW OF CONTROLLER .....</b>	<b>5</b>
1.1. 2 LED OUTPUT CONTROLLER.....	5
1.2. AVAILABLE CONTROL SOURCE .....	6
1.3. LED OUTPUT .....	7
1.3.1. Common Parameters .....	8
1.4. LOOKUP TABLE FUNCTION BLOCK.....	10
1.5. PROGRAMMABLE LOGIC FUNCTION BLOCK .....	11
1.6. CONSTANT DATA.....	13
1.7. MATH FUNCTION BLOCK.....	14
1.8. CONDITIONAL BLOCK .....	16
1.9. SET/RESET LATCH FUNCTION BLOCK .....	18
1.10. DIAGNOSTIC FUNCTION BLOCK.....	19
1.11. DTC REACT .....	23
1.12. CAN RECEIVE FUNCTION BLOCK.....	24
1.13. CAN TRANSMIT FUNCTION BLOCK.....	25
1.13.1. CAN Transmit Signal Setpoints .....	25
1.13.2. CAN Transmit Signal Setpoints .....	25
<b>2. INSTALLATION INSTRUCTIONS .....</b>	<b>27</b>
2.1 DIMENSIONS AND PINOUT .....	27
<b>3. OVERVIEW OF J1939 FEATURES .....</b>	<b>28</b>
3.1. INTRODUCTION TO SUPPORTED MESSAGES.....	28
3.2. NAME, ADDRESS AND SOFTWARE ID.....	30
3.2.1. J1939 Name .....	30
3.2.2. ECU Address .....	30
3.2.3. Software Identifier .....	30
<b>4. ECU SETPOINTS ACCESSED WITH THE AXIOMATIC ELECTRONIC ASSISTANT .....</b>	<b>32</b>
4.1. NETWORK SETPOINTS .....	32
4.2. LED OUTPUT SETPOINTS .....	33
4.3. CONSTANT DATA LIST .....	36
4.4. LOOKUP TABLE.....	37
4.5. PROGRAMMABLE LOGIC .....	39
4.6. MATH FUNCTION BLOCK.....	41
4.7. CONDITIONAL LOGIC BLOCK SETPOINTS .....	43
4.8. SET-RESET LATCH BLOCK .....	44
4.9. CAN TRANSMIT SETPOINTS.....	45
4.10. CAN RECEIVE SETPOINTS.....	47
4.11. GENERAL DIAGNOSTICS OPTIONS.....	48
4.12. DIAGNOSTICS BLOCKS .....	49
4.13. DTC REACT FUNCTION BLOCK.....	52
<b>5. REFLASHING OVER CAN WITH THE AXIOMATIC EA BOOTLOADER.....</b>	<b>53</b>
<b>6. VERSION HISTORY.....</b>	<b>59</b>
<b>APPENDIX A - TECHNICAL SPECIFICATIONS .....</b>	<b>60</b>

## ACCRONYMS

ACK	Positive Acknowledgement	(from SAE J1939 standard)
AOUT	Analog Output: Current, Voltage, Digital, PWM or frequency type	
DM	Diagnostic Message	(from SAE J1939 standard)
DOUT	Digital Output	
DTC	Diagnostic Trouble Code	(from SAE J1939 standard)
EA	Axiomatic Electronic Assistant	(A tool for Axiomatic ECUs)
ECU	Electronic Control Unit	(from SAE J1939 standard)
NAK	Negative Acknowledgement	(from SAE J1939 standard)
PDU1	A format for messages that are to be sent to a destination address, either specific or global (from SAE J1939 standard)	
PDU2	A format used to send information that has been labeled using the Group Extension technique and does not contain a destination address.	
PGN	Parameter Group Number	(from SAE J1939 standard)
PropA	Message that uses the Proprietary A PGN for peer-to-peer communication	
PropB	Message that uses a Proprietary B PGN for broadcast communication	
PWM	Pulse Width Modulation	
SPN	Suspect Parameter Number	(from SAE J1939 standard)

## REFERENCES

J1939	Recommended Practice for a Serial Control and Communications Vehicle Network, SAE, April 2011
J1939/21	Data Link Layer, SAE, December 2010
J1939/71	Vehicle Application Layer, SAE, March 2011
J1939/73	Application Layer-Diagnostics, SAE, February 2010
J1939/81	Network Management, SAE, March 2017
TDAX031600	Technical Datasheet, 2 LED Output CAN Controller
UMAX07050x	User Manual, Axiomatic Electronic Assistant and USB-CAN, Axiomatic Technologies

***This document assumes the reader is familiar with the SAE J1939 standard. Terminology from the standard is used but is not described in this document.***



NOTE: When a description is in “**double-quotes**” and bolded, this refers to the name of a user configurable setpoint (variable). If it is in ‘*single-quotes*’ and italicized, it refers to an option for the associated setpoint.

For example: “**Output Type**” set to ‘*Analog Current*’



This product uses the Axiomatic Electronic Assistant to program the setpoints for application specific requirements. After configuration, the setpoints can be saved in a file which could then be flashed into other AX031600 controllers over the CAN network.

## 1. OVERVIEW OF CONTROLLER

### 1.1. 2 LED Output Controller

The 2LED Output with CAN J1939 Controller is a versatile and high-performance solution for managing LED lighting in automotive and industrial applications. This controller supports two independent LED outputs, each capable of driving up to 600 mA, providing ample power for a variety of lighting configurations. It offers dual control modes, allowing for both direct current (DC) operation for steady illumination and pulse-width modulation (PWM) for dimming and dynamic lighting effects. Built on the reliable CAN J1939 protocol, the controller ensures seamless integration into existing vehicle or machine communication networks. Its flexibility and robust design make it ideal for demanding environments, delivering precise and reliable LED control across a wide range of applications. The J1939 CAN network can operate at standard 250 and 500kbit/s and non-standard 667kbit/s and 1Mbit/s baud rates. The required baud rate is detected automatically upon connection to the CAN network.




Figure 1 - Hardware Functional Block Diagram

## 1.2. Available Control Source

The controller output signal sources of all function blocks and source numbers are presented in the table below.

Signal Source Number	Signal Name	Signal Type	Source Number
0	Control Not Used	Undefined	0
1	Received CAN Message	Any <sup>2</sup>	[1...10]
2	Lookup Table	Any <sup>2</sup>	[1...10]
3	Programmable Logic Block	Any <sup>2</sup>	[1...4]
4	Math Function Block	Any <sup>2</sup>	[1...5]
5	Conditional Logic Block	Any <sup>2</sup>	[1...10]
6	Set-Reset Latch Logic Block	Any <sup>2</sup>	[1...5]
7	Control Constant Data	Any <sup>2</sup>	[1...15]
8	Power Supply Measured	Continuous	[0...255]
9	Processor Temperature Measured	Continuous	[0...255]
10	Receive Message Timeout	Discrete	[1...10]
11	DTC React	Any <sup>2</sup>	[1...16]

Table 1 - Controller Signal Sources

<sup>1</sup> Depends on the *Input Parameter*.

<sup>2</sup> Depends on the *Signal Type* configuration parameter.

### 1.3. LED Output

The 2LEDOUT provides advanced dimming capabilities, offering both DC and PWM dimming for each output. The PWM dimming is fully programmable, allowing adjustment of both duty cycle and frequency to achieve precise control over lighting effects. For static applications, each dimming mode can be set to a constant value, eliminating the need for active control. Additionally, the controller includes ramp-up and ramp-down functionality for smooth transitions between brightness levels, as well as enable and override controls for flexible operation. This versatile design ensures superior lighting management tailored to a wide range of applications, delivering comprehensive and adaptable LED control for diverse operational requirements.

The control signals for the outputs are associated with both minimum and maximum values. The LED outputs will always respond linearly to changes in the control source, following the calculations outlined in Equation 3.

$$y = mx + a$$

$$m = \frac{Y_{\max} - Y_{\min}}{X_{\max} - X_{\min}}$$

$$a = Y_{\min} - m * X_{\min}$$

*Equation 1 - Linear Slope Calculations*

Where X and Y are defined as:

$X_{\min}$  = Control Input Minimum

$Y_{\min}$  = **“Output At Minimum Command”**

$X_{\max}$  = Control Input Maximum

$Y_{\max}$  = **“Output At Maximum Command”**

In all cases, while the X-axis has the constraint that  $X_{\min} < X_{\max}$ , there is no such limitation on the Y-axis. This allows for a negative slope so that as the control input signal increases, the target output value decreases. Or it allows output to follow control signal inversely.

The LED output supports DC dimming with a current range of 80mA to 600mA, providing flexible current control for various LED applications. For PWM dimming, the duty cycle can be adjusted from 0% to 100%, with a frequency range spanning from 25 Hz to 100,000 Hz.

The controller also supports a blinking mode, which operates only when a fixed PWM frequency is enabled and set above 60 Hz. The default blink interval is 1000 ms. It is recommended to avoid excessively fast blinking, as it may cause unintended effects.

### 1.3.1. Common Parameters

In order to prevent abrupt changes at the output due to sudden changes in the command input, the user can choose to use the independent up or down ramps to smooth out the response. The **“Ramp Up (Min to Max)”** and **“Ramp Down (Max to Min)”** parameters are in milliseconds, and the step size of the output change will be determined by taking the absolute value of the output range and dividing it by the ramp time. However, these setpoints are set to zero by default since in most signal conversion applications, fast response times are desired.

By default, the **“Control Source”** is setup to be *‘CAN Receive Message’*. In other words, all the outputs will response in a linear fashion to the corresponding CAN received command data.

The **“Control Source”** together with **“Control Number”** parameter determine which signal is used to drive the output. For example, setting **“Control Source”** to *‘CAN Receive Message’* and **“Control Number”** to *‘1’* will connect signal measured from CAN Receive 1 to the output in question. The options for **“Control Sources”** and available **“Control Number”** are listed in Table 1.

In addition to the Control input, the function block also supports an enable input which can be setup as either an enable or disable signal.

When an Enable input is used, the output will be shutoff as per the **“Enable Response”** in Table 12. If the response is selected as a disabled signal (3 or 4), when the enable input is ON, the output will be shut off.

	Enable Response Options
0	Enable When On, Else Shutoff
1	Enable When Off, Else Shutoff
2	Enable When On, Else To Min
3	Enable When On, Else To Max
4	Enable When On, Else Ramp To Min
5	Enable When On, Else Ramp To Max
6	Enable When On, Else Keep Last Value
7	Enable When Off, Else Keep Last Value

*Table 2 - Enable Response Options*

The Override option allows the user to choose whether or not to drive the output with the override input being engaged/disengaged, depending on the logic selected in **“Override Response.”** The options for **“Override Response”** listed in Table 7. When override is active, the output will be driven to the value in **“Output at Override Command”** regardless of the value of the Control input.

Value	Meaning
0	Override When ON
1	Override When OFF

*Table 3 - Override Response Options*



The options for both “**Enable Source**” and “**Override Source**” are same as sources listed in Table 1.

Another fault response that can be enabled is that a power supply fault (under/over voltage) will automatically disable the outputs. Note: this setpoint is associated with the **Under Voltage Diagnostics** and Over **Voltage Diagnostics blocks**. Also, a microprocessor over-temperature fault can be used to disable all the outputs until it has cooled back to the operating range if the corresponding setpoints is enabled. These will be described in more details in Section 1.11.

## 1.4. Lookup Table Function Block

Lookup Tables are used to give output response up to 10 slopes per input. If more than 10 slopes are required, A Programmable Logic Block can be used to combine up to three tables to get 30 slopes as described in Section 1.6.

Lookup tables have two differing modes defined by “X-Axis Type” setpoint, given in Table 14. Option ‘0 – Data Response’ is the normal mode where block input signal is selected with the “X-Axis Source” and “X-Axis Number” setpoints and X values present directly input signal values. With option ‘1 – Time Response’ the input signal is time and X values present time in milliseconds. And selected input signal is used as digital enable.

Value	X-Axis Type
0	Data Response
1	Time Response

*Table 4 - X-Axis Type Options*

The slopes are defined with (x, y) points and associated point response. X value presents input signal value and Y value corresponding Lookup Table output value. “PointN – Response” setpoint defines type of the slope from preceding point to the point in question. Response options are given in Table 15. ‘Ramp To’ gives a linearized slope between points, whereas ‘Jump to’ gives a point-to-point response, where any input value between XN-1 and XN will result Lookup Table output being YN. “Point0 – Response” is always ‘Jump To’ and cannot be edited. Choosing ‘Ignored’ response causes associated point and all the following points to be ignored.

Value	Response
0	Ignore
1	Ramp To
2	Jump To

*Table 5 - PointN – Response Options*

The X values are limited by minimum and maximum range of the selected input source if the source is a Math Function Block. For the fore mentioned sources X-Axis data will be redefined when ranges are changed, therefore inputs should be adjusted before changing X-Axis values. For other sources Xmin and Xmax are -100000 and 1000000. The X-Axis is constraint to be in rising order, thus value of the next index is greater than or equal to preceding one. Therefore, when adjusting the X-Axis data, it is recommended that X10 is changed first, then lower indexes in descending order.

$$Xmin \leq X_0 \leq X_1 \leq X_2 \leq X_3 \leq X_4 \leq X_5 \leq X_6 \leq X_7 \leq X_8 \leq X_9 \leq X_{10} \leq Xmax$$

The Y-Axis has no constraints on the data it presents, thus inverse, decreasing, increasing or other response can be easily established. The Smallest of the Y-Axis values is used as Lookup Table output min and the largest of the Y-Axis values is used as Lookup Table output max (i.e. used as Xmin and Xmax values in linear calculation.). Ignored points are not considered for min and max values.

## 1.5. Programmable Logic Function Block

The Programmable Logic Function Block is a powerful tool. Programmable Logic can be linked to up to three Lookup Tables, any of which would be selected only under given conditions. Thus, the output of a Programmable Logic at any given time will be the output of the Lookup Table selected by the defined logic. Therefore, up to three different responses to the same input, or three different responses to different inputs, can become the input to another function block.

In order to enable any one of the Programmable Logic blocks, the “Logic Enabled” setpoint must be set to ‘True’. By default, all Logic blocks are disabled.

The three associated tables are selected by setting “Table Number X” setpoint to desired Lookup Table number, for example selecting 1 would set Lookup Table 1 as TableX.

For each TableX there are three conditions that define the logic to select the associated Lookup Table as Logic output. Each condition implements function *Argument1 Operator Argument2* where Operator is logical operator defined by setpoint “Table X – Condition Y Operator”. Setpoint options are listed in Table 16. Condition arguments are selected with “Table X – Condition Y Argument Z Source” and “Table X – Condition Y Argument Z Number” setpoints. If ‘0 – Control not Used’ option is selected as “Table x – Condition Y Argument Z Source” the argument is interpreted as 0.

Value	Operator
0	=, Equal
1	!=, Not Equal
2	>, Greater Than
3	>=, Greater Than or Equal
4	<, Less Than
5	<=, Less Than or Equal

Table 6 - Table X – Condition Y Operator Options

The three conditions are evaluated and if the result satisfies logical operation defined with “Logical Operator X” setpoint, given in Table 17, the associated Lookup Table is selected as output of the Logical block. Option ‘0 – Default Table’ selects associated Lookup Table in all conditions.

Value	Logical Operator
0	Default Table (Table1)
1	Cnd1 And Cnd2 And Cnd3
2	Cnd1 Or Cnd2 Or Cnd3
3	(Cnd1 And Cnd2) Or Cnd3
4	(Cnd1 Or Cnd2) And Cnd3

Table 7 - Table X – Conditions Logical Operator Options

The three logical operations are evaluated in order and the first to satisfy gets selected, thus if Table1 logical operation is satisfied, the Lookup Table associated with Table1 gets selected regardless of two other logical operations. In addition, if none of the logical operations is satisfied the Lookup Table associated with Table1 gets selected.

## **1.6. Constant Data**

The Constant Data Block contains 2 fixed (False/True) and 13 configurable constant data setpoints which can be used as a control source for other functions. While they are available as a control source for all functions, it is recommended not to use constant data as a control source for the Set-Reset Latch Block.

## 1.7. Math Function Block

There are five mathematical function blocks that allow the user to define basic algorithms. A math function block can take up to six input signals. Each input is then scaled according to the associated limit and scaling setpoints.

Inputs are converted into percentage value based on the “Input X Minimum” and “Input X Maximum” values selected. For additional control the user can also adjust the “Input X Gain” setpoint to increase the resolution of the input data and the min and max values.

A mathematical function block includes three selectable functions, in which each implements equation A operator B, where A and B are function inputs and operator is function selected with a setpoint “Math Function X”. Setpoint options are presented in Table 18. The functions are connected together, so that result of the preceding function goes into Input A of the next function. Thus Function 1 has both Input A and Input B selectable with setpoints, where Functions 2 to 4 have only Input B selectable. Input is selected by setting “Function X Input Y Source” and “Function X Input Y Number”. If “Function X Input B Source” is set to 0 ‘Control not used’ signal goes through function unchanged.

$$\text{Math Block Output} = (((A1 \text{ op1 } B1) \text{ op2 } B2) \text{ op3 } B3) \text{ op4 } B4$$

Value	Meaning
0	=, True when InA equals InB
1	!=, True when InA not equal InB
2	>, True when InA greater than InB
3	>=, True when InA greater than or equal InB
4	<, True when InA less than InB
5	<=, True when InA less than or equal InB
6	OR, True when InA or InB is True
7	AND, True when InA and InB are True
8	XOR, True when either InA or InB is True, but not both
9	+, Result = InA plus InB
10	-, Result = InA minus InB
11	x, Result = InA times InB
12	/, Result = InA divided by InB
13	MIN, Result = Smallest of InA and InB
14	MAX, Result = Largest of InA and InB

Table 8 - Math function X Operator Options

For logic operations (6, 7, and 8) scaled input greater than or equal to 1 is treated as TRUE. For logic operations (0 to 8), the result of the function will always be 0 (FALSE) or 1 (TRUE). For the arithmetic functions (9 to 14), it is recommended to scale the data such that the resulting operation will not exceed full scale (0 to 100%) and saturate the output result.

When dividing, a zero divider will always result in a 100% output value for the associated function.

Lastly the resulting mathematical calculation, presented as a percentage value, can be scaled into the appropriate physical units using the “Math Output Minimum Range” and “Math Output Maximum Range” setpoints. These values are also used as the limits when the Math Function is selected as the input source for another function block.

## 1.8. Conditional Block

The Conditional Block compares up to four different input sources with different logical or relational operators. The result of each block can therefore only be true (1) or false (0). Figure 2 demonstrates the connections between all parameters.




Figure 1: Conditional Block Diagram

Each Conditional Block offers two conditions. Both compare two inputs, which can hold a logical value or an integer value. The output of the conditions can only be true or false and will be compared by Operator 3 with a logical operator. This comparison is the result of the Conditional Block and can control any output source.

Value of each source will then be compared to each other with an operator of Table 19. If no source is selected, the output value of an Input will be zero.

Value	Meaning
0	==, True when Argument 1 is equal to Argument 2
1	!=, True when Argument 1 is not equal to Argument 2
2	>, True when Argument 1 is greater than Argument 2
3	>=, True when Argument 1 is greater than Argument 2
4	<, True when Argument 1 is less than Argument 2
5	<=, True when Argument 1 is less than or equal Argument 2
6	OR, True when Argument 1 or Argument 2 is True
7	AND, True when Argument 1 and Argument 2 are True

Table 9 - Input Operator Options

Operator 1 and Operator 2 are configured to OR by default. The table above cannot be used for comparing the conditions because they can only be compared with logical operators, which are listed in Table 20.



Value	Meaning
0	OR, True when Argument 1 or Argument 2 is True
1	AND, True when Argument 1 and Argument 2 are True
2	XOR, True when Argument 1 is not equal to Argument 2

*Table 10 - Condition Operator Options*

If only one condition is used, it is to make sure that Operator 3 is set to OR so that the result is based solely on the condition which has been chosen.

### 1.9. Set/Reset Latch Function Block

Set-Reset Block consists of only 2 control sources: Reset Source and Set Source. The purpose of these blocks is to simulate a modified latching function in which the 'Reset Signal' has more precedence. The 'latching' function works as per the Table 21 below.

'Set Signal'	'Reset Signal'	'Set-Reset Block Output' (Initial State: OFF)
OFF	OFF	Latched State
OFF	ON	OFF
ON	OFF	ON
ON	ON	OFF

*Table 11 - Set-Reset Function block operation.*

The Reset and Set sources have associated with them a minimum and maximum threshold values which determine the ON and OFF state. For the Reset Source are Reset Minimum Threshold and Reset Maximum Threshold. Similarly, for the Set Source are Set Minimum Threshold and Set Maximum Threshold. These setpoints also allow to have a dead band in between ON/OFF states and they are in terms of percentage of input selected.

As seen in Table 21 above, the 'Reset Signal' has more precedence over the 'Set Signal' - if the state of 'Reset Signal' is ON, the state of 'Set-Reset Block Output' will be OFF. To create an ON state in 'Set-Reset Block Output' the state of 'Reset Signal' must be OFF while the state of 'Set Signal' is ON. In this case, the state of 'Set-Reset Block Output' will remain ON even if 'Set Signal' turns OFF as long as 'Reset Signal' remains OFF. As soon as the 'Reset Signal' turns ON the 'Set-Reset Block Output' will turn OFF regardless of the state of 'Set Signal'.

## 1.10. Diagnostic Function Block

This ECU supports diagnostic messaging. DM1 message is a message, containing Active Diagnostic Trouble Codes (DTC) that is sent to the J1939 network in case a fault has been detected. A Diagnostic Trouble Code is defined by the J1939 standard as a four-byte value which is a combination of:

SPN	Suspect Parameter Number	(User defined)
FMI	Failure Mode Identifier	(See Table 24)
CM	Conversion Method	(Always set to 0)
OC	Occurrence Count	(Number of times the fault has happened)

In addition to supporting the DM1 message, The CAN Controller Input also supports:

DM2	Previously Active Diagnostic Trouble Codes	Sent only on request
DM3	Diagnostic Data Clear/Reset of Previously Active DTCs	Done only on request
DM11	Diagnostic Data Clear/Reset for Active DTCs	Done only on request

Fault detection and reaction is a standalone functionality that can be configured to monitor and report diagnostics of various controller parameters. The CAN Controller supports 16 Diagnostics Definitions, each freely configurable by the user.

By default, the monitoring of operating voltage, CPU temperature and receive message timeouts is configured to diagnostics blocks 1, 2 and 3., In case any of these three diagnostics blocks are needed for some other use, the default settings can be adjusted by the user to suit the application.

There are 4 fault types that can be used, “**Minimum and maximum error**”, “**Absolute value error**”, “**State error**” and “**Double minimum and maximum error**”.

**Minimum and maximum error** has two thresholds, “MIN Shutdown” and “MAX Shutdown” that have configurable, independent diagnostics parameters (SPN, FMI, Generate DTCs, delay before flagging status). In case the parameter to monitor stays between these two thresholds, the diagnostic is not flagged.

**Absolute value error** has one configurable threshold with configurable parameters. In case the parameter to monitor stays below this threshold, the diagnostic is not flagged.

**State error** is similar to the Absolute value error, the only difference is that State error does not allow the user to specify specific threshold values; thresholds ‘1’ and ‘0’ are used instead. This is ideal for monitoring state information, such as received message timeouts.

**Double minimum and maximum error** lets user to specify four thresholds, each with independent diagnostic parameters. The diagnostic status and threshold values is determined and expected as show in Figure 3 below.




Figure 2 – Double Minimum and Maximum Error Thresholds

In case any of the Diagnostics blocks is configured to monitor Output Current Feedback, there is an internal error status flag maintained automatically for that particular output. This internal flag can be used for driving the particular output to a specified state in case of diagnostic event using Proportional Current Output setpoints “Control Fault Response”, “Output in Fault Mode” and “Fault Detection Enabled”.

There is also built in error status flags for power supply and CPU temperature monitoring. In case any of the diagnostics blocks is measuring these two parameters, the corresponding internal error status flags can be used for shutting down the unit in case of failure. The setpoints “**Power Fault Disables Outputs**” and “**Over Temperature Shutdown**” can be used for enabling the shutdown of the unit (shutdown == output driving is turned off).

While there are no active DTCs, the CAN Controller will send “No Active Faults” message. If a previously inactive DTC becomes active, a DM1 will be sent immediately to reflect this. As soon as the last active DTC goes inactive, a DM1 indicating that there are no more active DTCs will be sent.

If there is more than one active DTC at any given time, the regular DM1 message will be sent using a multipacket message to the Requester Address using the Transport Protocol (TP).



At power up, the DM1 message will not be broadcasted until after 5 second delay. This is done to prevent any power up or initialization conditions from being flagged as an active error on the network.

When the fault is linked to a DTC, a non-volatile log of the occurrence count (OC) is kept. As soon as the controller detects a new (previously inactive) fault, it will start decrementing the **“Delay before Event is flagged”** timer for that Diagnostic function block. If the fault has remained present during the delay time, then the controller will set the DTC to active, and will increment the OC in the log. A DM1 will immediately be generated that includes the new DTC. The timer is provided so that intermittent faults do not overwhelm the network as the fault comes and goes, since a DM1 message would be sent every time the fault shows up or goes away.

By default, the fault flag is cleared when error condition that has caused it goes away. The DTC is made Previously Active and is it is no longer included in the DM1 message. To identify a fault having happened, even if the condition that has caused is one away, the **“Event Cleared only by DM11”** setpoint can be set to *‘True’*. This configuration enables DTC to stay Active, even after the fault flag has been cleared, and be included in DM1 message until a Diagnostic Data Clear/Reset for Active DTCs (DM11) has been requested.

As defined by J1939 Standard the first byte of the DM1 message reflects the Lamp status. **“Lamp Set by Event”** setpoint determines the lamp type set in this byte of DTC. **“Lamp Set by Event”** setpoint options are listed in Table 22. By default, the *‘Amber, Warning’* lamp is typically the one set by any active fault.

Value	Event
0	<i>Protect</i>
1	<i>Amber Warning</i>
2	<i>Red Stop</i>
3	<i>Malfunction</i>

Table 12 - Lamp Set by Event in DM1 Options

**“SPN for Event”** defines suspect parameter number used as part of DTC. The default value zero is not allowed by the standard, thus no DM will be sent unless **“SPN for Event”** is configured to be different from zero. **It is the user’s responsibility to select SPN that will not violate J1939 standard.** When the **“SPN for Event”** is changed, the OC of the associated error log is automatically reset to zero.

Value	Option
0	<i>Data Valid But Above Normal Operational Range - Most Severe Level</i>
1	<i>Data Valid But Below Normal Operational Range - Most Severe Level</i>
2	<i>Data Intermittent</i>
3	<i>Voltage Above Normal, Or Shorted To High Source</i>
4	<i>Voltage Below Normal, Or Shorted To Low Source</i>
5	<i>Current Below Normal Or Open Circuit</i>
6	<i>Current Above Normal Or Grounded Circuit</i>
7	<i>Mechanical Error</i>
8	<i>Abnormal Frequency Or Pulse Width Or Period</i>
9	<i>Abnormal Update Rate</i>
10	<i>Abnormal Rate Of Change</i>
11	<i>Root Cause Not Known</i>
12	<i>Bad Component</i>
13	<i>Out Of Calibration</i>
14	<i>Special Instructions</i>
15	<i>Data Valid But Above Normal Operating Range – Least Severe Level</i>
16	<i>Data Valid But Above Normal Operating Range – Moderately Severe Level</i>
17	<i>Data Valid But Below Normal Operating Range – Least Severe Level</i>
18	<i>Data Valid But Below Normal Operating Range – Moderately Severe Level</i>
19	<i>Network Error</i>
20	<i>Data Drifted High</i>
21	<i>Data Drifted Low</i>
31	<i>Condition Exists</i>

Table 13 - FMI for Event Options

Every fault has associated a default FMI with them. The used FMI can be configured with “**FMI for Event**” setpoint, presented in Table 23. When an FMI is selected from Low Fault FMIs in Table 24 for a fault that can be flagged either high or low occurrence, it is recommended that the user would select the high occurrence FMI from the right column of Table 24. There is no automatic setting of High and Low FMIs in the firmware, the user can configure these freely.

Low Fault FMIs	High Fault FMIs
<i>FMI=1, Data Valid But Below Normal Operation Range – Most Severe Level</i>	<i>FMI=0, Data Valid But Above Normal Operational Range – Most Severe Level</i>
<i>FMI=4, Voltage Below Normal, Or Shorted to Low Source</i>	<i>FMI=3, Voltage Above Normal, Or Shorted To High Source</i>
<i>FMI=5, Current Below Normal Or Open Circuit</i>	<i>FMI=6, Current Above Normal Or Grounded Circuit</i>
<i>FMI=17, Data Valid But Below Normal Operating Range – Least Severe Level</i>	<i>FMI=15, Data Valid But Above Normal Operating Range – Least Severe Level</i>
<i>FMI=18, Data Valid But Below Normal Operating Level – Moderately Severe Level</i>	<i>FMI=16, Data Valid But Above Normal Operating Range – Moderately Severe Level</i>
<i>FMI=21, Data Drifted Low</i>	<i>FMI=20, Data Drifted High</i>

Table 14 - Low Fault FMIs and corresponding High Fault FMIs

### 1.11. DTC React

DTC React is a function block that allows the ECU to receive and process the DM1 messages. There are 16 separated function blocks that can capture up to 16 different DM1 messages. Each DTC React has two mandatory and 2 optional parameters. The mandatory parameters are the SPN and FMI. If only these parameters are used, the output will be set to high if the DM1 message with the combination of selected SPN and FMI. The state will remain high for five seconds and will be set if the DM1 message will be received again.

Among optional parameters there are lamp setting and the source address. To enable them, the “**Lamp Used to Trigger Reaction**” and “**Source Address Used to Trigger Reaction**” should be set to 1, *True*. In this case, beside SPN and FMI the ECU will compare the Lamp Setting and/or Source Address of the received message.

The exceptions are the following SPN:

- SPN 1213 and Lamp Status 0x40.
- SPN623 and Lamp Status 0x10.
- SPN624 and Lamp Status 0x04.
- SPN624 and Lamp Status 0x01.

In case if the SPNs above are chosen, the DTC React function block will set the output to HIGH if SPN and Lamp Status match even if FMI doesn't match. However, if the “**Source Address Used to Trigger Reaction**” is set to 1, *True* and selected address doesn't match, the DTC React output will be set to FALSE.

## 1.12. CAN Receive Function Block

The CAN Receive function block is designed to take any SPN from the J1939 network and use it as an input to another function block (i.e. Outputs).

“**CAN Interface**” setpoint is used to define from which of the two CAN Interfaces the message in question is received.

The “**Receive Message Enabled**” is the most important setpoint associated with this function block and it should be selected first. Changing it will result in other setpoints being enabled/disabled as appropriate. By default, ALL receive messages are disabled.

Once a message has been enabled, a Lost Communication fault will be flagged if that message is not received off the bus within the “**Receive Message Timeout**” period. This could trigger a Lost Communication event as described in section 1.11. In order to avoid timeouts on a heavily saturated network, it is recommended to set the period at least three times longer than the expected update rate. To disable the timeout feature, simply set this value to zero, in which case the received message will never trigger a Lost Communication fault.

By default, all control messages are expected to be sent to this controller on Proprietary B PGNs. However, should a PDU1 message be selected, this Controller can be set up to receive it from any ECU by setting the “**Specific Address that sends the PGN**” to the Global Address (0xFF). If a specific address is selected instead, then any other ECU data on the PGN will be ignored.

The “**Receive Data Size**”, “**Receive Data Index in Array (LSB)**”, “**Receive Bit Index in Byte (LSB)**”, “**Receive Resolution**” and “**Receive Offset**” can all be used to map any SPN supported by the J1939 standard to the output data of the Received function block.

As mentioned earlier, a CAN receive function clock can be selected as the source of the control input for the output function blocks. When this is the case, the “**Received Data Min (Off Threshold)**” and “**Received Data Max (On Threshold)**” setpoints determine the minimum and maximum values of the control signal. As the names imply, they are also used as the On/Off thresholds for digital output types. These values are in whatever units the data is AFTER the resolution and offset is applied to CAN receive signal.

This Controller supports up to Ten unique CAN Receive Messages. Default setpoint values are listed in section 4.11.



### 1.13. CAN Transmit Function Block

The CAN Transmit function block is used to send any output from another function block (i.e. input, CAN receive) to the J1939 network. The AX031600 ECU has five CAN Transmit Messages, and each message has four completely user defined signals.

#### 1.13.1. CAN Transmit Signal Setpoints

Each CAN Transmit Message setpoint group includes setpoints that effect the whole message and are thus mutual for all signals of the message. These setpoints are presented in this section. The setpoints that configure an individual signal are presented in next section.

The “**Transmit PGN**” setpoint sets PGN used with the message. **User should be familiar with the SAE J1939 standard, and select values for PGN/SPN combinations as appropriate from section J1939/71.**

“**Repetition Rate**” setpoint defines the interval used to send the message to the J1939 network. If the “**Repetition Rate**” is set to zero, the message is disabled unless it shares its PGN with another message. In case of a shared PGN repetition rate of the LOWEST numbered message are used to send the message ‘bundle’.



At power up, transmitted message will not be broadcasted until after a 5 second delay. This is done to prevent any power up or initialization conditions from creating problems on the network.

By default, all messages are sent on Proprietary B PGNs as broadcast messages. Thus “**Transmit Message Priority**” is always initialized to 6 (low priority) and the “**Destination Address**” setpoint is not used. This setpoint is only valid when a PDU1 PGN has been selected, and it can be set either to the Global Address (0xFF) for broadcasts or sent to a specific address as setup by the user.

#### 1.13.2. CAN Transmit Signal Setpoints

Each CAN transmit message has four associated signals, which define data inside the Transmit message. “**Control Source**” setpoint together with “**Control Number**” setpoint define the signal source of the message. “**Control Source**” and “**Control Number**” options are listed in Table 1. Setting “**Control Source**” to ‘*Control Not Used*’ disables the signal.

**“Transmit Data Size”** setpoint determines how many bits signal reserves from the message. **“Transmit Data Index in Array”** determines in which of 8 bytes of the CAN message LSB of the signal is located. Similarly, **“Transmit Bit Index in Byte”** determines in which of 8 bits of a byte the LSB is located. These setpoints are freely configurable, thus **it is the user’s responsibility to ensure that signals do not overlap and mask each other.**

**“Transmit Data Resolution”** setpoint determines the scaling done on the signal data before it is sent to the bus. **“Transmit data Offset”** setpoint determines the value that is subtracted from the signal data before it is scaled. Offset and Resolution are interpreted in units of the selected source signal.

## 2. Installation Instructions

### 2.1 Dimensions and Pinout




Figure 16 –Dimensional Drawing

Pin	Function
1	Battery +
2	CAN H
3	LED 2 +
4	LED 1 +
5	LED 1 -
6	LED 2 -
7	CAN L
8	Battery -

Table 19 – Connector Pinout

### 3. OVERVIEW OF J1939 FEATURES

---

The software was designed to provide flexibility to the user with respect to messages sent to and from the ECU by providing:

- Configurable ECU Instance in the NAME (to allow multiple ECUs on the same network)
- Configurable Transmit PGN and SPN Parameters
- Configurable Receive PGN and SPN Parameters
- Sending DM1 Diagnostic Message Parameters
- Reading and reacting to DM1 messages sent by other ECUs
- Diagnostic Log, maintained in non-volatile memory, for sending DM2 messages

#### 3.1. Introduction To Supported Messages

The ECU is compliant with the standard SAE J1939, and supports the following PGNs

##### From J1939-21 - Data Link Layer

- |  |                  |
|--|------------------|
| • Request  | 59904 (\$00EA00) |
| • Acknowledgment                                     | 59392 (\$00E800) |
| • Transport Protocol – Connection Management         | 60416(\$00EC00)  |
| • Transport Protocol – Data Transfer Message         | 60160 (\$00EB00) |
| • PropB Receive, Default Output Control Data Message | 65408 (\$00FF80) |

Note: Any Proprietary B PGN in the range 65280 to 65535 (\$00FF00 to \$00FFFF) can be selected

Note: The Proprietary A PGN 61184 (\$00EF00) can also be selected for any of the messages

##### From J1939-73 - Diagnostics

- |   |                  |
|---|------------------|
| a) DM1 – Active Diagnostic Trouble Codes                        | 65226 (\$00FECA) |
| b) DM2 – Previously Active Diagnostic Trouble Codes             | 65227 (\$00FECB) |
| c) DM3 – Diagnostic Data Clear/Reset for Previously Active DTCs | 65228 (\$00FECC) |
| d) DM11 - Diagnostic Data Clear/Reset for Active DTCs           | 65235 (\$00FED3) |
| e) DM14 – Memory Access Request                                 | 55552 (\$00D900) |
| f) DM15 – Memory Access Response                                | 55296 (\$00D800) |
| g) DM16 – Binary Data Transfer                                  | 55040 (\$00D700) |

##### From J1939-81 - Network Management

- |                                |                  |
|--------------------------------|------------------|
| • Address Claimed/Cannot Claim | 60928 (\$00EE00) |
| • Commanded Address            | 65240 (\$00FED8) |

##### From J1939-71 – Vehicle Application Layer

- |                           |                  |
|---------------------------|------------------|
| • Software Identification | 65242 (\$00FEDA) |
|---------------------------|------------------|

None of the application layer PGNs are supported as part of the default configurations, but they can be selected as desired for either transmit or received function blocks.

Setpoints are accessed using standard Memory Access Protocol (MAP) with proprietary addresses. The Axiomatic Electronic Assistant (EA) allows for quick and easy configuration of the unit over the CAN network.

## 3.2. Name, Address and Software ID

### 3.2.1. J1939 Name

The unit has the following defaults for the J1939 NAME. The user should refer to the SAE J1939/81 standard for more information on these parameters and their ranges.

Arbitrary Address Capable	Yes
Industry Group	0, Global
Vehicle System Instance	0
Vehicle System	0, Non-specific system
Function	124, Axiomatic I/O Controller
Function Instance	0, Axiomatic AX031600, CAN to 2 LED Outputs Controller
<b>ECU Instance</b>	<b>0, First Instance</b>
Manufacture Code	162, Axiomatic Technologies Corporation
Identity Number	Variable, uniquely assigned during factory programming for each ECU

The ECU Instance is a configurable setpoint associated with the NAME. Changing this value will allow multiple ECUs of this type to be distinguishable by other ECUs (including the Axiomatic Electronic Assistant) when they are all connected on the same network.

### 3.2.2. ECU Address

The default value of this setpoint is 128 (0x80), which is the preferred starting address for self-configurable ECUs as set by the SAE in J1939 tables B3 to B7. The Axiomatic EA will allow the selection of any address between 0 to 253, and ***it is the user's responsibility to select an address that complies with the standard.*** The user must also be aware that since the unit is arbitrary address capable, if another ECU with a higher priority NAME contends for the selected address, the unit will continue select the next highest address until it finds one that it can claim. See J1939/81 for more details about address claiming.


### 3.2.3. Software Identifier

PGN 65242		Software Identification		- SOFT
Transmission Repetition Rate:		On request		
Data Length:		Variable		
Extended Data Page:		0		
Data Page:		0		
PDU Format:		254		
PDU Specific:		218 PGN Supporting Information:		
Default Priority:		6		
Parameter Group Number:		65242 (0xFEDA)		
Start Position	Length	Parameter Name	SPN	
1	1 Byte	Number of software identification fields	965	
2-n	Variable	Software identification(s), Delimiter (ASCII “*”)	234	

For this unit, Byte 1 is set to 1, and the identification fields are as follows

**(Part Number)\*(Version)\*(Date)\*(Owner)\*(Description)**

The Axiomatic EA shows all this information in “General ECU Information”, as shown below:



Parameter	Value	Description
ECU Part Number	AX031600	
ECU Serial Number	0000121001	
ECU J1939 NAME		PGN 60928. 64-bit ECU Identifier sent in Address Claimed Messages
Arbitrary Address Capable	0X01	Yes
Industry Group	0X00	Global
Vehicle System Instance	0X00	
Vehicle System	0X00	Non-specific system
Reserved	0X00	
Function	0X7C	Reserved
Function Instance	0X00	
ECU Instance	0X00	#1 - First Instance
Manufacturer Code	0X0A2	Axiomatic Technologies
Identity Number	0X178BB5	Unique ECU network ID number
ECU Address	0X80	Reserved for future assignment by SAE, but available for use by self configurable ECUs
ECU ID		PGN 64965 -ECUID
ECU Part Number	AX031600	
ECU Serial Number	0000121001	
ECU Type	Controller	
ECU Manufacturer Name	Axiomatic	
Software ID		PGN 65242 -SOFT
Field #1	CAN to 2 LED Outputs Controller	
Field #2	Firmware: V99.99, November 2024	


*Note: The information provided in the Software ID is available for any J1939 service tool which supports the PGN -SOFT*

## 4. ECU SETPOINTS ACCESSED WITH THE AXIOMATIC ELECTRONIC ASSISTANT

Many setpoints have been referenced throughout this manual. This section describes in detail each setpoint, and their defaults and ranges. For more information on how each setpoint is used by the controller, refer to the relevant section of the User Manual.

### 4.1. Network Setpoints

The Network setpoints primarily deal with the CAN Network. Refer to the notes for more information about each setpoint.



**Screen Capture of Default Miscellaneous Setpoints**


Name	Range	Default	Notes
ECU Instance Number	Drop List	0, #1 – First Instance	Per J1939-81
ECU Address	0 to 253	128 (0x80)	Preferred address for a self-configurable ECU

mirrored during a setpoint file flashing and will only take effect once the entire file has been downloaded to the unit. After the setpoint flashing is complete, the unit will claim the new address and/or re-claim the address with the new NAME. If these setpoints are changing, it is recommended to close and re-open the CAN connection on the Axiomatic EA after the file is loaded, such that only the new NAME and address appear in the J1939 CAN Network ECU list.



## 4.2. LED Output Setpoints

The LED Output are defined in section in Section 1.3. Please refer to detailed information about how all these setpoints are used.



Setpoint Name	Value	Comment
SP LED Output Enable	0	Disabled
SP Fixed DC Enabled		Parameter not used with current Output Type selected
SP Fixed DC Value		Parameter not used with current Output Type selected
SP DC Control Source		Parameter not used with current Output Type selected
SP DC Control Number		Parameter not used with current Output Type selected
SP DC Control Response		Parameter not used with current Output Type selected
SP DC Enable Source		Parameter not used with current Output Type selected
SP DC Enable Number		Parameter not used with current Output Type selected
SP DC Enable Response		Parameter not used with current Output Type selected
SP DC Override Source		Parameter not used with current Output Type selected
SP DC Override Number		Parameter not used with current Output Type selected
SP DC Override Response		Parameter not used with current Output Type selected
SP DC at Override Command		Parameter not used with current Output Type selected
SP DC Fault Response		Parameter not used with current Output Type selected
SP DC at Fault Command		Parameter not used with current Output Type selected
SP DC at Minimum Command		Parameter not used with current Output Type selected
SP DC at Maximum Command		Parameter not used with current Output Type selected
SP DC Ramp Up (Min to Max)		Parameter not used with current Output Type selected
SP DC Ramp Down (Max to Min)		Parameter not used with current Output Type selected
SP Fixed PWM Frequency Enabled		Parameter not used with current Output Type selected
SP Fixed PWM Frequency Value		Parameter not used with current Output Type selected
SP PWM Frequency Control Source		Parameter not used with current Output Type selected
SP PWM Frequency Control Number		Parameter not used with current Output Type selected
SP PWM Frequency Control Response		Parameter not used with current Output Type selected
SP PWM Frequency Enable Source		Parameter not used with current Output Type selected
SP PWM Frequency Enable Number		Parameter not used with current Output Type selected
SP PWM Frequency Enable Response		Parameter not used with current Output Type selected
SP PWM Frequency Override Source		Parameter not used with current Output Type selected
SP PWM Frequency Override Number		Parameter not used with current Output Type selected
SP PWM Frequency Override Response		Parameter not used with current Output Type selected
SP PWM Frequency at Override Command		Parameter not used with current Output Type selected
SP PWM Frequency Fault Response		Parameter not used with current Output Type selected
SP PWM Frequency at Fault Command		Parameter not used with current Output Type selected
SP PWM Frequency at Minimum Command		Parameter not used with current Output Type selected

Figure 3 - Screen Capture of Default Input Setpoints


Name	Range	Default	Notes
LED Output Enable	Drop List	Disabled	See Section 1.3
Fixed DC Enable	Drop List	Disabled	See Section 1.3
Fixed DC Value	80...600	80	See Section 1.3
DC Control Source	Drop List	0, Control Not Used	Refer to Table 1
DC Control Number		0	Refer to Table 1
DC Control Response	Drop List	0, Single Output Profile	Refer to Section 1.3.1
DC Enable Source	Drop List	0, Control Not Used	Refer to Table 1
DC Enable Number		0	Refer to Table 1
DC Enable Response	Drop List	0, Enable When on Else Shutoff	Refer to Section 1.3.1
DC Override Source	Drop List	0, Control Not Used	Refer to Table 1
DC Override Number		0	Refer to Table 1
DC Override Response	Drop List	0, Override when ON	Refer to Section 1.3.1
DC Output at Override Command	80...600	80	Refer to Section 1.3.1
DC Fault Response	Drop List	0, Output Shutdown	Refer to Section 1.3.1
DC at Fault Command	80-600	80	Refer to Section 1.3.1
DC At Minimum Command	80...600	80	Refer to Section 1.3.1
DC At Maximum Command	80...600	600	Refer to Section 1.3.1
DC Ramp Up (Min to Max)	0...10000	1000	Refer to Section 1.3.1
DC Ramp Down (Max to Min)	0...10000	0	Refer to Section 1.3.1
Fixed PWM Frequency Enable	Drop List	Disabled	See Section 1.3
Fixed PWM Frequency Value	25...100000	5000	See Section 1.3
PWM Frequency Control Source	Drop List	0, Control Not Used	Refer to Table 1
PWM Frequency Control Number		0	Refer to Table 1
PWM Frequency Control Response	Drop List	0, Single Output Profile	Refer to Section 1.3.1
PWM Frequency Enable Source	Drop List	0, Control Not Used	Refer to Table 1
PWM Frequency Enable Number		0	Refer to Table 1
PWM Frequency Enable Response	Drop List	0, Enable When on Else Shutoff	Refer to Section 1.3.1
PWM Frequency Override Source	Drop List	0, Control Not Used	Refer to Table 1
PWM Frequency Override Number		0	Refer to Table 1
PWM Frequency Override Response	Drop List	0, Override when ON	Refer to Section 1.3.1
PWM Frequency Output at Override Command	25...100000	5000	Refer to Section 1.3.1
PWM Frequency Fault Response	Drop List	0, Output Shutdown	Refer to Section 1.3.1
PWM Frequency at Fault Command	25...100000	5000	Refer to Section 1.3.1
PWM Frequency At Minimum Command	25...100000	25	Refer to Section 1.3.1
PWM Frequency At Maximum	25...100000	100000	Refer to Section 1.3.1

Command			
PWM Frequency Ramp Up (Min to Max)	0...10000	1000	Refer to Section 1.3.1
PWM Frequency Ramp Down (Max to Min)	0...10000	0	Refer to Section 1.3.1
Fixed PWM Duty Cycle Enable	Drop List	Disabled	See Section 1.3
Fixed PWM Duty Cycle Value	0...100	50	See Section 1.3
PWM Duty Cycle Control Source	Drop List	0, Control Not Used	Refer to Table 1
PWM Duty Cycle Control Number		0	Refer to Table 1
PWM Duty Cycle Control Response	Drop List	0, Single Output Profile	Refer to Section 1.3.1
PWM Duty Cycle Enable Source	Drop List	0, Control Not Used	Refer to Table 1
PWM Duty Cycle Enable Number		0	Refer to Table 1
PWM Duty Cycle Enable Response	Drop List	0, Enable When on Else Shutoff	Refer to Section 1.3.1
PWM Duty Cycle Override Source	Drop List	0, Control Not Used	Refer to Table 1
PWM Duty Cycle Override Number		0	Refer to Table 1
PWM Duty Cycle Override Response	Drop List	0, Override when ON	Refer to Section 1.3.1
PWM Duty Cycle Output at Override Command	0...100	50	Refer to Section 1.3.1
PWM Duty Cycle Fault Response	Drop List	0, Output Shutdown	Refer to Section 1.4.4
PWM Duty Cycle at Fault Command	0...100	50	Refer to Section 1.3.1
PWM Duty Cycle At Minimum Command	0...100	0	Refer to Section 1.3.1
PWM Duty Cycle At Maximum Command	0...100	100	Refer to Section 1.3.1
PWM Duty Cycle Ramp Up (Min to Max)	0...10000	1000	Refer to Section 1.3.1
PWM Duty Cycle Ramp Down (Max to Min)	0...10000	0	Refer to Section 1.3.1
LED Blink Mode	0...65000	1000	Refer to Section 1.3.1

### 4.3. Constant Data List

The Constant Data List Function Block is provided to allow the user to select values as desired for various logic block functions.

The first two constants are fixed values of 0 (False) and 1 (True) for use in binary logic. The remaining 13 constants are fully user programmable to any value between +/- 1 000 000. The default values (shown in Figure 6) are arbitrary and should be configured by the user as appropriate for their application.




The screenshot shows the 'Electronic Assistant' window with the 'Constant Data List' setpoint selected. The table displays 15 setpoints: two fixed constants (FALSE and TRUE) and 13 user-programmable constants, all currently set to 0.0000000.

Setpoint Name	Value	Comment
SP Constant FALSE (fixed)	False	(Read Only)
SP Constant TRUE (fixed)	True	(Read Only)
SP Constant Value 3	0.0000000	
SP Constant Value 4	0.0000000	
SP Constant Value 5	0.0000000	
SP Constant Value 6	0.0000000	
SP Constant Value 7	0.0000000	
SP Constant Value 8	0.0000000	
SP Constant Value 9	0.0000000	
SP Constant Value 10	0.0000000	
SP Constant Value 11	0.0000000	
SP Constant Value 12	0.0000000	
SP Constant Value 13	0.0000000	
SP Constant Value 14	0.0000000	

Figure 4 – Screen Capture of Constant Data List Setpoints

## 4.4. Lookup Table

The Lookup Table Function Block is defined in Section 10. Please refer there for detailed information about how all these setpoints are used. “**X-Axis Source**” is set to ‘*Control Not Used*’ by default. To enable a Lookup Table select appropriate “**X-Axis Source**”.



Setpoint Name	Value	Comment
SP X-Axis Source	1	Received CAN Message
SP X-Axis Number	1	
SP X-Axis Type	0	Data Response
SP Auto Repeat	0	False
SP Response 1	0	Ignore
SP Response 2		Parameter not used when a previous Response is set to Ignore
SP Response 3		Parameter not used when a previous Response is set to Ignore
SP Response 4		Parameter not used when a previous Response is set to Ignore
SP Response 5		Parameter not used when a previous Response is set to Ignore
SP Response 6		Parameter not used when a previous Response is set to Ignore
SP Response 7		Parameter not used when a previous Response is set to Ignore
SP Response 8		Parameter not used when a previous Response is set to Ignore
SP Response 9		Parameter not used when a previous Response is set to Ignore
SP Response 10		Parameter not used when a previous Response is set to Ignore
SP Point X0	0.000	
SP Point X1		Parameter not used when a previous Response is set to Ignore
SP Point X2		Parameter not used when a previous Response is set to Ignore
SP Point X3		Parameter not used when a previous Response is set to Ignore
SP Point X4		Parameter not used when a previous Response is set to Ignore
SP Point X5		Parameter not used when a previous Response is set to Ignore
SP Point X6		Parameter not used when a previous Response is set to Ignore
SP Point X7		Parameter not used when a previous Response is set to Ignore
SP Point X8		Parameter not used when a previous Response is set to Ignore
SP Point X9		Parameter not used when a previous Response is set to Ignore
SP Point X10		Parameter not used when a previous Response is set to Ignore
SP Point Y0	0.000	
SP Point Y1		Parameter not used when a previous Response is set to Ignore
SP Point Y2		Parameter not used when a previous Response is set to Ignore
SP Point Y3		Parameter not used when a previous Response is set to Ignore
SP Point Y4		Parameter not used when a previous Response is set to Ignore
SP Point Y5		Parameter not used when a previous Response is set to Ignore
SP Point Y6		Parameter not used when a previous Response is set to Ignore
SP Point Y7		Parameter not used when a previous Response is set to Ignore
SP Point Y8		Parameter not used when a previous Response is set to Ignore
SP Point Y9		Parameter not used when a previous Response is set to Ignore
SP Point Y10		Parameter not used when a previous Response is set to Ignore

Figure 5 – Screen Capture of Lookup table Setpoints


Name	Range	Default	Notes
X-Axis Source	Drop List	Control Not Used	See Table 1
X-Axis Number	Depends on control source	1	See Table 1
X-Axis Type	Drop List	Data Response	See Table 14
Table Auto-Cycle	Drop List	0	
Point 1 - Response	Drop List	Ramp To	See Table 15
Point 2 - Response	Drop List	Ramp To	See Table 15
Point 3 - Response	Drop List	Ramp To	See Table 15
Point 4 - Response	Drop List	Ramp To	See Table 15
Point 5 - Response	Drop List	Ramp To	See Table 15
Point 6 - Response	Drop List	Ramp To	See Table 15
Point 7 - Response	Drop List	Ramp To	See Table 15
Point 8 - Response	Drop List	Ramp To	See Table 15
Point 9 - Response	Drop List	Ramp To	See Table 15
Point 10 - Response	Drop List	Ramp To	See Table 15
Point 1 - X Value	From X-Axis source minimum to Point 1 - X Value	X-Axis source minimum 0.000	See Section 1.5
Point 2 - X Value	From Point 0 - X Value to Point 2 - X Value	0.500	See Section 1.5
Point 3 - X Value	From Point 1 - X Value to Point 3 - X Value	1.000	See Section 1.5
Point 4 - X Value	From Point 2 - X Value to Point 4 - X Value	1.500	See Section 1.5
Point 5 - X Value	From Point 3 - X Value to Point 5 - X Value source	2.000	See Section 1.5
Point 6 - X Value	From Point 4 - X Value to Point 6 - X Value	2.500	See Section 1.5
Point 7 - X Value	From Point 5 - X Value to Point 7 - X Value	3.000	See Section 1.5
Point 8 - X Value	From Point 6 - X Value to Point 8 - X Value	3.500	See Section 1.5
Point 9 - X Value	From Point 7 - X Value to Point 9 - X Value	4.000	See Section 1.5
Point 10 - X Value	From Point 8 - X Value to Point 10 - X Value	4.500	See Section 1.5
Point 1 - Y Value	-10 <sup>6</sup> to 10 <sup>6</sup>	0.000	
Point 2 - Y Value	-10 <sup>6</sup> to 10 <sup>6</sup>	10.000	
Point 3 - Y Value	-10 <sup>6</sup> to 10 <sup>6</sup>	20.000	
Point 4 - Y Value	-10 <sup>6</sup> to 10 <sup>6</sup>	30.000	
Point 5 - Y Value	-10 <sup>6</sup> to 10 <sup>6</sup>	40.000	
Point 6 - Y Value	-10 <sup>6</sup> to 10 <sup>6</sup>	50.000	
Point 7 - Y Value	-10 <sup>6</sup> to 10 <sup>6</sup>	60.000	
Point 8 - Y Value	-10 <sup>6</sup> to 10 <sup>6</sup>	70.000	
Point 9 - Y Value	-10 <sup>6</sup> to 10 <sup>6</sup>	80.000	
Point 10 - Y Value	-10 <sup>6</sup> to 10 <sup>6</sup>	90.000	

*Table 15 - Lookup Table Setpoints*



## 4.5. Programmable Logic

The Programmable Logic function block is defined in Section 1.6. Please refer there for detailed information about how all these setpoints are used. **“Programmable Logic Enabled”** is ‘False’ by default. To enable Logic set **“Programmable Logic Enabled”** to ‘True’ and select appropriate **“Argument Source”**.



The screenshot shows the 'Electronic Assistant' window with a menu bar (File, View, Options, Help) and a toolbar. The main area displays a table of setpoints for 'Programmable Logic 1'. The table has three columns: Setpoint Name, Value, and Comment. The setpoints are organized into sections for Logic Enabled, Table 1, and Table 2, each with various conditions and arguments. Most values are 1 or 0, and comments indicate parameters not used with the current logical operator selected.

Setpoint Name	Value	Comment
SP Logic Enabled	1	True
SP Table Number 1	1	Lookup Table 1
SP Logical Operator 1	0	Default Table
SP Table 1 - Condition 1 Argument 1 Source		Parameter not used with current Logical Operator selected
SP Table 1 - Condition 1 Argument 1 Number		Parameter not used with current Logical Operator selected
SP Table 1 - Condition 1 Argument 2 Source		Parameter not used with current Logical Operator selected
SP Table 1 - Condition 1 Argument 2 Number		Parameter not used with current Logical Operator selected
SP Table 1 - Condition 1 Operator		Parameter not used with current Logical Operator selected
SP Table 1 - Condition 2 Argument 1 Source		Parameter not used with current Logical Operator selected
SP Table 1 - Condition 2 Argument 1 Number		Parameter not used with current Logical Operator selected
SP Table 1 - Condition 2 Argument 2 Source		Parameter not used with current Logical Operator selected
SP Table 1 - Condition 2 Argument 2 Number		Parameter not used with current Logical Operator selected
SP Table 1 - Condition 2 Operator		Parameter not used with current Logical Operator selected
SP Table 1 - Condition 3 Argument 1 Source		Parameter not used with current Logical Operator selected
SP Table 1 - Condition 3 Argument 1 Number		Parameter not used with current Logical Operator selected
SP Table 1 - Condition 3 Argument 2 Source		Parameter not used with current Logical Operator selected
SP Table 1 - Condition 3 Argument 2 Number		Parameter not used with current Logical Operator selected
SP Table 1 - Condition 3 Operator		Parameter not used with current Logical Operator selected
SP Table Number 2	1	Lookup Table 1
SP Logical Operator 2	0	Default Table
SP Table 2 - Condition 1 Argument 1 Source		Parameter not used with current Logical Operator selected
SP Table 2 - Condition 1 Argument 1 Number		Parameter not used with current Logical Operator selected
SP Table 2 - Condition 1 Argument 2 Source		Parameter not used with current Logical Operator selected
SP Table 2 - Condition 1 Argument 2 Number		Parameter not used with current Logical Operator selected
SP Table 2 - Condition 1 Operator		Parameter not used with current Logical Operator selected
SP Table 2 - Condition 2 Argument 1 Source		Parameter not used with current Logical Operator selected
SP Table 2 - Condition 2 Argument 1 Number		Parameter not used with current Logical Operator selected
SP Table 2 - Condition 2 Argument 2 Source		Parameter not used with current Logical Operator selected
SP Table 2 - Condition 2 Argument 2 Number		Parameter not used with current Logical Operator selected
SP Table 2 - Condition 2 Operator		Parameter not used with current Logical Operator selected
SP Table 2 - Condition 3 Argument 1 Source		Parameter not used with current Logical Operator selected

Figure 6 – Screen Capture of Programmable Logic Setpoints

Setpoint ranges and default values for Programmable Logic Blocs are listed in Table 27. Only “**Table1**” setpoint are listed, because other “**TableX**” setpoints are similar, except for the default value of the “**Lookup Table Block Number**” setpoint, which is X for “**TableX**”.


Name	Range	Default	Notes
Programmable Logic Enabled	Drop List	False	
Table1 - Lookup Table Block Number	1 to 8	Look up Table 1	
Table1 - Conditions Logical Operation	Drop List	Default Table	See Table 17
Table1 - Condition1, Argument 1 Source	Drop List	Control Not Used	See Table 1
Table1 - Condition1, Argument 1 Number	Depends on control source	1	See Table 1
Table1 - Condition1, Operator	Drop List	=, Equal	See Table 16
Table1 - Condition1, Argument 2 Source	Drop List	Control Not Used	See Table 1
Table1 - Condition1, Argument 2 Number	Depends on control source	1	See Table 1
Table1 - Condition2, Argument 1 Source	Drop List	Control Not Used	See Table 1
Table1 - Condition2, Argument 1 Number	Depends on control source	1	See Table 1
Table1 - Condition2, Operator	Drop List	=, Equal	See Table 16
Table1 - Condition2, Argument 2 Source	Drop List	Control Not Used	See Table 1
Table1 - Condition2, Argument 2 Number	Depends on control source	1	See Table 1
Table1 - Condition3, Argument 1 Source	Drop List	Control Not Used	See Table 1
Table1 - Condition3, Argument 1 Number	Depends on control source	1	See Table 1
Table1 - Condition3, Operator	Drop List	=, Equal	See Table 16
Table1 - Condition3, Argument 2 Source	Drop List	Control Not Used	See Table 1
Table1 - Condition3, Argument 2 Number	Depends on control source	1	See Table 1

*Table 16 - Programmable Logic Setpoints*



## 4.6. Math Function Block

The Math Function Block is defined in Section 1.8 Please refer there for detailed information about how all these setpoints are used. “**Math Function Enabled**” is ‘False’ by default. To enable a Math function Block, set “**Math Function Enabled**” to ‘True’ and select appropriate “**Input Source**”.



Setpoint Name	Value	Comment
SP Math Enabled	1	True
SP Math Output Minimum Range	0.00	
SP Math Output Maximum Range	100.00	
SP Input 1 Source	0	Control Not Used
SP Input 1 Number		Parameter not used with current Control Source selected
SP Input 1 Minimum		Parameter not used with current Control Source selected
SP Input 1 Maximum		Parameter not used with current Control Source selected
SP Input 1 Gain		Parameter not used with current Control Source selected
SP Input 2 Source	0	Control Not Used
SP Input 2 Number		Parameter not used with current Control Source selected
SP Input 2 Minimum		Parameter not used with current Control Source selected
SP Input 2 Maximum		Parameter not used with current Control Source selected
SP Input 2 Gain		Parameter not used with current Control Source selected
SP Input 3 Source	0	Control Not Used
SP Input 3 Number		Parameter not used with current Control Source selected
SP Input 3 Minimum		Parameter not used with current Control Source selected
SP Input 3 Maximum		Parameter not used with current Control Source selected
SP Input 3 Gain		Parameter not used with current Control Source selected
SP Input 4 Source	0	Control Not Used
SP Input 4 Number		Parameter not used with current Control Source selected
SP Input 4 Minimum		Parameter not used with current Control Source selected
SP Input 4 Maximum		Parameter not used with current Control Source selected
SP Input 4 Gain		Parameter not used with current Control Source selected
SP Math Function 1		Parameter not used with current Control Source selected
SP Math Function 2		Parameter not used with current Control Source selected
SP Math Function 3		Parameter not used with current Control Source selected

Figure 7 – Screen Capture of Math Function Block Setpoints

Name	Range	Default	Notes
Math Function Enabled	Drop List	False	
Function 1 Input A Source	Drop List	Control not used	See Table 1
Function 1 Input A Number	Depends on control source	1	See Table 1
Function 1 Input A Minimum	$-10^6$ to $10^6$	0.0	
Function 1 Input A Maximum	$-10^6$ to $10^6$	100.0	
Function 1 Input A Scaler	-1.00 to 1.00	1.00	
Function 1 Input B Source	Drop List	Control not used	See Table 1
Function 1 Input B Number	Depends on control source	1	See Table 1
Function 1 Input B Minimum	$-10^6$ to $10^6$	0.0	
Function 1 Input B Maximum	$-10^6$ to $10^6$	100.0	
Function 1 Input B Scaler	-1.00 to 1.00	1.00	
Math Function 1 Operation	Drop List	=, True when InA Equals InB	See Table 18
Function 2 Input B Source	Drop List	Control not used	See Table 1
Function 2 Input B Number	Depends on control source	1	See Table 1
Function 2 Input B Minimum	$-10^6$ to $10^6$	0.0	
Function 2 Input B Maximum	$-10^6$ to $10^6$	100.0	
Function 2 Input B Scaler	-1.00 to 1.00	1.00	
Math Function 3 Operation	Drop List	=, True when InA Equals InB	See Table 18
Function 3 Input B Source	Drop List	Control not used	See Table 1
Function 3 Input B Number	Depends on control source	1	See Table 1
Function 3 Input B Minimum	$-10^6$ to $10^6$	0.0	
Function 3 Input B Maximum	$-10^6$ to $10^6$	100.0	
Function 3 Input B Scaler	-1.00 to 1.00	1.00	
Math Function 3 Operation	Drop List	=, True when InA Equals InB	See Table 18
Function 4 Input B Source	Drop List	Control not used	See Table 1
Function 4 Input B Number	Depends on control source	1	See Table 1
Function 4 Input B Minimum	$-10^6$ to $10^6$	0.0	
Function 4 Input B Maximum	$-10^6$ to $10^6$	100.0	
Function 4 Input B Scaler	-1.00 to 1.00	1.00	
Math Function 4 Operation	Drop List	=, True when InA Equals InB	See Table 18
Math Output Minimum Range	$-10^6$ to $10^6$	0.0	
Math Output Maximum Range	$-10^6$ to $10^6$	100.0	

Table 17 - Math Function Setpoints

## 4.7. Conditional Logic Block Setpoints

The Conditional Block setpoints are defined in Section 1.9. Refer to that section for detailed information on how these setpoints are used. The screen capture in Figure 10 displays the available setpoints for each of the Conditional Blocks. The table below the screen capture highlights the allowable ranges for each setpoint.




Figure 8: Screen Capture of Conditional Block Setpoints

Name	Range	Default	Notes
Conditional Function Enabled	Drop List	Disabled	
Condition 1 Argument 1 Source	Drop List	Digital Input	Refer to Table 1
Condition 1 Argument 1 Number	Depends on Source Selected	0	Refer to Table 1
Condition 1 Argument 2 Source	Drop List	Digital Input	Refer to Table 1
Condition 1 Argument 2 Number	Depends on Source Selected	0	Refer to Table 1
Condition 1 Operator (Argument 1/2)	Drop List	0	Refer to Table 19
Condition 2 Argument 1 Source	Drop List	Digital Input	Refer to Table 1
Condition 2 Argument 1 Number	Depends on Source Selected	0	Refer to Table 1
Condition 2 Argument 2 Source	Drop List	Digital Input	Refer to Table 1
Condition 2 Argument 2 Number	Depends on Source Selected	0	Refer to Table 1
Condition 2 Operator (Argument 1/2)	Drop List	0	Refer to Table 19
Conditional Result Operator	Drop List	OR	Refer to Table 20

Table 18 - Default Conditional Block Setpoints

## 4.8. Set-Reset Latch Block

The Set-Reset Latch Block setpoints are defined in Section 1.10. Refer to that section for detailed information on how these setpoints are used. The screen capture in Figure 11 displays the available setpoints for each of the Set-Reset Latch Blocks. The table below the screen capture highlights the allowable ranges for each setpoint.





Figure 9: Screen Capture of Set-Reset Latch Block Setpoints

Name	Range	Default	Notes
Block Enabled	Drop List	False	
Reset Source	Drop List	Control Not Used	Refer to Table 1
Reset Number	Depends on Source Selected	1	Refer to Table 1
Reset Minimum Threshold	Drop List	0%	Refer to Section 1.10
Reset Maximum Threshold	Depends on Source Selected	100%	Refer to Section 1.10
Set Source	Drop List	Control Not Used	Refer to Table 1
Set Number	Drop List	1	Refer to Table 1
Set Minimum Threshold	Depends on Source Selected	0%	Refer to Section 1.10
Set Maximum Threshold	Drop List	100%	Refer to Section 1.10

Table 19 - Default Set-Reset Latch Block Setpoints

## 4.9. CAN Transmit Setpoints

CAN Transmit Message Function Block be presented in section 1.14. Please refer there for detailed information how these setpoints are used. **“Transmit Repetition Rate”** is 0ms by default, thus no message will be sent.



Setpoint Name	Value	Comment
SP CAN Interface	1	CAN Interface 1
SP Transmit Enabled	0	False
SP PGN		Parameter not used - Transmit Message is Disabled
SP Repetition Rate		Parameter not used - Transmit Message is Disabled
SP Message Priority		Parameter not used - Transmit Message is Disabled
SP Destination Address (PDU1)		Parameter not used - Transmit Message is Disabled
SP Message Length		Parameter not used - Transmit Message is Disabled
SP Signal 1 Data Type		Parameter not used - Transmit Message is Disabled
SP Signal 1 Data Source		Parameter not used - Transmit Message is Disabled
SP Signal 1 Data Number		Parameter not used - Transmit Message is Disabled
SP Signal 1 Data Size		Parameter not used - Transmit Message is Disabled
SP Signal 1 Byte Index		Parameter not used - Transmit Message is Disabled
SP Signal 1 Bit Index		Parameter not used - Transmit Message is Disabled
SP Signal 1 Resolution		Parameter not used - Transmit Message is Disabled
SP Signal 1 Offset		Parameter not used - Transmit Message is Disabled
SP Signal 1 Data Min		Parameter not used - Transmit Message is Disabled
SP Signal 1 Data Max		Parameter not used - Transmit Message is Disabled
SP Signal 2 Data Type		Parameter not used - Transmit Message is Disabled
SP Signal 2 Data Source		Parameter not used - Transmit Message is Disabled
SP Signal 2 Data Number		Parameter not used - Transmit Message is Disabled
SP Signal 2 Data Size		Parameter not used - Transmit Message is Disabled
SP Signal 2 Byte Index		Parameter not used - Transmit Message is Disabled
SP Signal 2 Bit Index		Parameter not used - Transmit Message is Disabled
SP Signal 2 Resolution		Parameter not used - Transmit Message is Disabled
SP Signal 2 Offset		Parameter not used - Transmit Message is Disabled
SP Signal 2 Data Min		Parameter not used - Transmit Message is Disabled
SP Signal 2 Data Max		Parameter not used - Transmit Message is Disabled
SP Signal 3 Data Type		Parameter not used - Transmit Message is Disabled
SP Signal 3 Data Source		Parameter not used - Transmit Message is Disabled
SP Signal 3 Data Number		Parameter not used - Transmit Message is Disabled
SP Signal 3 Data Size		Parameter not used - Transmit Message is Disabled
SP Signal 3 Byte Index		Parameter not used - Transmit Message is Disabled
SP Signal 3 Bit Index		Parameter not used - Transmit Message is Disabled

Figure 10 – Screen Capture of CAN Transmit Message Setpoints

Name	Range	Default	Notes
CAN Interface	Drop List	CAN Interface #1	
Transmit Enabled	Drop List	0, False	
Transmit PGN	0xff00 ... 0xffff	Different for each	See section 1.14.1
Transmit Repetition Rate	0 ... 65000 ms	0ms	0ms disables transmit
Transmit Message Priority	0...7	6	Proprietary B Priority
Destination Address	0...255	255	Not used by default
Signal X Control Source	Drop List	Different for each	See Table 1
Signal X Control Number	Drop List	Different for each	See Table 1
Signal X Transmit Data Size	Drop List	2 bytes	
Signal X Transmit Data Index in Array	0-7	0	
Signal X Transmit Bit Index In Byte	0-7	0	
Signal X Transmit Data Resolution	-100000.0 to 100000	1/bits	
Signal X Transmit Data Offset	-10000 to 10000	0.0	
Signal X Transmit Data Minimum	-100000.0 to 100000	0.0	
Signal X Transmit Data Maximum	-100000.0 to 100000	65535.0	

*Table 20 - CAN Transmit Message Setpoints*

## 4.10. CAN Receive Setpoints

The CAN Receive Block is defined in section 1.13. Please refer there for detailed information about how these setpoints are used. **“Receive Message Timeout”** is set to 0ms by default. To enable Receive message set **“Receive Message Timeout”** that differs from zero.




Figure 11 – Screen Capture of CAN Receive Message Setpoints

Name	Range	Default	Notes
CAN Interface	Drop List	CAN Interface #1	
Received Message Enabled	Drop List	False	
Received PGN	0 to 65536	Different for each	
Received Message Timeout	0 to 60 000 ms	0ms	
Specific Address that sends PGN	0 to 255	254 (0xFE, Null Addr)	
Receive Transmit Data Size	Drop List	2 bytes	
Receive Transmit Data Index in Array	0-7	4	
Receive Transmit Bit Index In Byte	0-7	0	
Receive Transmit Data Resolution	-100000.0 to 100000	0.001	
Receive Transmit Data Offset	-10000 to 10000	0.0	
Receive Data Min (Off Threshold)	-1000000 to Max	0.0	
Receive Data Max (On Threshold)	-100000 to 100000	2.0	

Table 21 - CAN Receive Setpoints

## 4.11. General Diagnostics Options

These setpoints control the shutdown of the ECU in case of a power supply or CPU temperature related errors. Refer to section 1.11 for more info.




Figure 12 – Screen Capture of General Diagnostics Options Setpoints

Name	Range	Default	Notes
Power Fault Disables Outputs	Drop List	0	
Over Temperature Shutdown	Drop List	0	

Table 22 - General Diagnostics Options Setpoints



## 4.12. Diagnostics Blocks

There are 16 Diagnostics blocks that can be configured to monitor various parameters of the Controller. The Diagnostic Function Block is defined in section 1.11. Please refer there for detailed information on how these setpoints are used.




Figure 13 – Screen Capture of Diagnostic Block Setpoints

Name	Range	Default	Notes
Fault Detection is Enabled	Drop List	False	
Function Type to Monitor	Drop List	0 – Control not used	
Function parameter to Monitor	Drop List	0 – No selection	
Fault Detection Type	Drop List	0 – Min and Max Error	See section 1.11
Maximum Value for Diagnostic Data	Minimum Value for Diagnostic Data ... 4.28e <sup>9</sup>	5.0	
Minimum Value for Diagnostic Data	0.0 ... Maximum Value for Diagnostic Data	0.0	
Use Hysteresis When Defining Thresholds	Drop List	False	

Hysteresis	0.0 ... Maximum Value for Diagnostic Data	0.0	
Event Cleared only by DM11	Drop List	False	
Set Limit for MAXIMUM SHUTDOWN	Minimum Value for Diagnostic Data ... Maximum Value for Diagnostics Data	4.8	
Clear Limit for MAXIMUM SHUTDOWN	Minimum Value for Diagnostic Data ... Maximum Value for Diagnostics Data	4.6	
Set Limit for MAXIMUM WARNING	Minimum Value for Diagnostic Data ... Maximum Value for Diagnostics Data	0.0	
Clear Limit for MAXIMUM WARNING	Minimum Value for Diagnostic Data ... Maximum Value for Diagnostics Data	0.0	
Clear Limit for MINIMUM WARNING	Minimum Value for Diagnostic Data ... Maximum Value for Diagnostics Data	0.0	
Set Limit for MINIMUM WARNING	Minimum Value for Diagnostic Data ... Maximum Value for Diagnostics Data	0.0	
Clear Limit for MINIMUM SHUTDOWN	Minimum Value for Diagnostic Data ... Maximum Value for Diagnostics Data	0.4	
Set Limit for MINIMUM SHUTDOWN	Minimum Value for Diagnostic Data ... Maximum Value for Diagnostics Data	0.2	
MAXIMUM SHUTDOWN, Event Generates a DTC in DM1	Drop List	True	
MAXIMUM SHUTDOWN, Lamp Set by Event	Drop List	0 – Protect	See Table 22
MAXIMUM SHUTDOWN, SPN for Event	0...524287	520448 (\$7F100)	It is the user's responsibility to select an SPN that will not violate the J1939 standard.
MAXIMUM SHUTDOWN, FMI for Event	Drop List	3, Voltage Above Normal	See Table 23

MAXIMUM SHUTDOWN, Delay Before Event is Flagged	0...60000 ms	1000	
MAXIMUM WARNING, Event Generates a DTC in DM1	Drop List	True	
MAXIMUM WARNING, Lamp Set by Event	Drop List	0 – Protect	See Table 22
MAXIMUM WARNING, SPN for Event	0...524287	520704 (\$7F200)	It is the user's responsibility to select an SPN that will not violate the J1939 standard.
MAXIMUM WARNING, FMI for Event	Drop List	3, Voltage Above Normal	See Table 23
MAXIMUM WARNING, Delay Before Event is Flagged	0...60000 ms	1000	
MINIMUM WARNING, Event Generates a DTC in DM1	Drop List	True	
MINIMUM WARNING, Lamp Set by Event	Drop List	0 – Protect	See Table 22
MAXIMUM WARNING, SPN for Event	0...524287	520960 (\$7F300)	It is the user's responsibility to select an SPN that will not violate the J1939 standard.
MINIMUM WARNING, FMI for Event	Drop List	4, Voltage Below Normal	See Table 23
MINIMUM WARNING, Delay Before Event is Flagged	0...60000 ms	1000	
MINIMUM SHUTDOWN, Event Generates a DTC in DM1	Drop List	True	
MINIMUM SHUTDOWN, Lamp Set by Event	Drop List	Amber Warning	See Table 22
MINIMUM SHUTDOWN, SPN for Event	0...524287	521216 (\$7F400)	It is the user's responsibility to select an SPN that will not violate the J1939 standard.
MINIMUM SHUTDOWN, FMI for Event	Drop List	4, Voltage Below Normal	See Table 23
MINIMUM SHUTDOWN, Delay Before Event is Flagged	0...60000 ms	1000	

Table 23 - Diagnostic Block Setpoints

### 4.13. DTC React Function Block

The DTC React function block is described in Section 1.12. The Figure below shows the DTC React function block setpoints. The Table below shows the default values. Please note: *The setpoint “DTC React is Enabled” was changed to 1, True.*




Figure 14 DTC React Setpoints


Name	Range	Default	Notes
DTC React is Enabled	Drop List	0, False	
SPN to Trigger Reaction	0x00 to 0x3FFFF	0	
FMI to Trigger Reaction	Drop List	0	
Lamp Used to Trigger Reaction	Drop list	0, False	
Lamp to Trigger Reaction	Drop List	0, Protect	
Source Address Used to Trigger Reaction	Drop list	0, False	
Source Address to Trigger Reaction	0x00 to 0xFF	0	

Table 24 - DTC React Setpoints


## 5. REFLASHING OVER CAN WITH THE AXIOMATIC EA BOOTLOADER

The AX031600 can be upgraded with new application firmware using the **Bootloader Information** section. This section details the simple step-by-step instructions to upload new firmware provided by Axiomatic onto the unit via CAN, without requiring it to be disconnected from the J1939 network.


1. When the Axiomatic EA first connects to the ECU, the **Bootloader Information** section will display the following information.



2. To use the bootloader to upgrade the firmware running on the ECU, change the variable “**Force Bootloader to Load on Reset**” to Yes.



- When the prompt box asks if you want to reset the ECU, select Yes.



- Upon reset, the ECU will no longer show up on the J1939 network as an AX031600 but rather as **J1939 Bootloader #1**.

The top screenshot shows the "Electronic Assistant" window with the "J1939 CAN Network" tree on the left. The "J1939 Bootloader #1" node is selected. The right pane shows a table with the following data:


ECU	J1939 NAME	Address	J1939 Preferred ...
ECU J1939 Bootloader #1	0X00FEFF001459879E	0XFD	Reserved for OEM

The bottom screenshot shows the "Electronic Assistant" window with the "General ECU Information" tab selected for "J1939 Bootloader #1". The right pane shows a table with the following data:

Parameter	Value	Description
ECU Part Number	AX030560	
ECU Serial Number	0000121001	
ECU J1939 NAME		PGN 60928, 64-bit ECU Identifier sent in Address Claimed Messages
Arbitrary Address Capable	0X00	No
Industry Group	0X00	Global
Vehicle System Instance	0X00	
Vehicle System	0X7F	Not Available
Reserved	0X00	
Function	0XFF	Not Available
Function Instance	0X00	
ECU Instance	0X00	#1 - First Instance
Manufacturer Code	0X0A2	Axiomatic Technologies
Identity Number	0X19879E	Unique ECU network ID number
ECU Address	0XFD	Reserved for OEM
ECU ID	N/A	PGN 64965 -ECUID
Software ID	N/A	PGN 65242 -SOFT

*Note that the bootloader is NOT Arbitrary Address Capable. This means that if you want to have multiple bootloaders running simultaneously (not recommended) you would have to manually change the address for each one before activating the next, or there will be address conflicts, and only one ECU would show up as the bootloader. Once the 'active' bootloader returns to regular functionality, the other ECU(s) would have to be power cycled to re-activate the bootloader feature.*


- When the **Bootloader Information** section is selected, the same information is shown as when it was running the AX031600 firmware, but in this case the **Flashing** feature has been enabled.



- Select the **Flashing** button and navigate to where you had saved the **AF-20017\_x.yy.bin** file sent from Axiomatic. (Note: only binary (.bin) files can be flashed using the Axiomatic EA tool)

- Once the Flash Application Firmware window opens, you can enter comments such as “Firmware upgraded by [Name]” if you so desire. This is not required, and you can leave the field blank if you do not want to use it.


Note: You do not have to date/time-stamp the file, as this is done automatically by the EA tool when you upload the new firmware.




**WARNING:** Do not check the “Erase All ECU Flash Memory” box unless instructed to do so by your Axiomatic contact. Selecting this will erase ALL data stored in non-volatile flash, including the calibration done by Axiomatic during factory testing. It will also erase any configuration of the setpoints that might have been done to the ECU and reset all setpoints to their factory defaults. By leaving this box unchecked, none of the setpoints will be changed when the new firmware is uploaded.



8. A progress bar will show how much of the firmware has been sent as the upload progresses. The more traffic there is on the J1939 network, the longer the upload process will take.



9. Once the firmware has finished uploading, a message will popup indicating the successful operation. If you select to reset the ECU, the new version of the AX031600 application will start running, and the ECU will be identified as such by the Axiomatic EA. Otherwise, the next time the ECU is power-cycled, the AX031600 application will run rather than the bootloader function.



Note: If at any time during the upload the process is interrupted, the data is corrupted (bad checksum) or for any other reason the new firmware is not correct, i.e. bootloader detects that the file loaded was not designed to run on the hardware platform, the bad or corrupted application will not run. Rather, when the ECU is reset or power-cycled the **J1939 Bootloader** will continue to be the default application until valid firmware has been successfully uploaded into the unit.

## 6. VERSION HISTORY

---

Version	Date	Author	Modifications
1.0.0	Dec. 16, 2024	Weixin Kong	Initial Draft
1.0.1	Apr. 10, 2025	M Ejaz	Marketing review Updated the block diagram, dimensional drawing, pin out table, and technical specifications

## APPENDIX A - Technical Specifications

Specifications are indicative and subject to change. Actual performance will vary depending on the application and operating conditions. Users should satisfy themselves that the product is suitable for use in the intended application. All our products carry a limited warranty against defects in material and workmanship. Please refer to our Warranty, Application Limitations & Return Materials Process as described on <https://www.axiomatic.com/service/>.

### Power

Power Supply	12 or 24 Vdc nominal 9 to 36 Vdc power supply range
Quiescent Current	<b>TBD mA @ 12 Vdc; TBD mA @ 24 Vdc typical</b>
Protection	Surge and transient protection up to 202 Vdc Reverse polarity protection up to -100 Vdc Undervoltage protection provided. Hardware shutdown at 6 Vdc. Overvoltage protection provided. Hardware shutdown at 38 V.

### Outputs

Outputs	2 outputs to power LEDs LED dimming option is provided via CAN.  <u>Voltage:</u> 28 Vdc max.  <u>Current:</u> Programable from 20 mA to 600 mA via CAN or hardware. 600 mA max. per output
Protection	Overcurrent and overvoltage protection provided

### General Specifications

Microcontroller	STM32H725RGV3, 32-bit, 1 Mbyte flash memory, 564 kbytes SRAM																		
Control Logic	Standard embedded software is provided. Refer to the user manual. (Application-specific control logic or factory programmed set point file on request)																		
Communication	1 CAN port (SAE J1939) Supported baud rate: 250 kbit/s, 500 kbit/s, 667 kbit/s, and 1 Mbit/s with auto-baud-rate detection																		
Network Termination	It is necessary to terminate the network with external termination resistors. The resistors are 120 Ω, 0.25 W minimum, metal film or similar type. They should be placed between CAN H and CAN L terminals at both ends of the network.																		
User Interface	Axiomatic Electronic Assistant P/Ns: <b>AX070502</b> or <b>AX070506K</b>																		
Compliance	RoHS																		
Operating Conditions	-40 to 85 °C (-40 to 185 °F)																		
Storage Temperature	-40 to 85 °C (-40 to 185 °F)																		
Protection	IP67																		
Weight	<b>0.196 lb. (0.089 kg) preliminary</b>																		
Enclosure and Dimensions	Molded enclosure, integral connector Nylon 6/6, 30% glass, laser welded 4.23 in. x 3.69 in. x 1.41 in. (107.4 mm x 93.7 mm x 35.8 mm) L x W x H includes the integral connector. Refer to Dimensional Drawing. Flammability rating: UL 94 HB																		
Electrical Connections	Integral 8-pin receptacle (equivalent to TE Deutsch P/N: <b>DT04-08PA</b> ) <table border="1"> <thead> <tr> <th>Pin</th><th>Function</th></tr> </thead> <tbody> <tr> <td>1</td><td>Battery +</td></tr> <tr> <td>2</td><td>CAN H</td></tr> <tr> <td>3</td><td>LED 2 +</td></tr> <tr> <td>4</td><td>LED 1 +</td></tr> <tr> <td>5</td><td>LED 1 -</td></tr> <tr> <td>6</td><td>LED 2 -</td></tr> <tr> <td>7</td><td>CAN L</td></tr> <tr> <td>8</td><td>Battery -</td></tr> </tbody> </table>	Pin	Function	1	Battery +	2	CAN H	3	LED 2 +	4	LED 1 +	5	LED 1 -	6	LED 2 -	7	CAN L	8	Battery -
Pin	Function																		
1	Battery +																		
2	CAN H																		
3	LED 2 +																		
4	LED 1 +																		
5	LED 1 -																		
6	LED 2 -																		
7	CAN L																		
8	Battery -																		
Mating Plugs	Axiomatic P/N: <b>AX070112</b> (includes TE Deutsch parts: 1 socket DT06-08SA, 1 wedgelock W8S, 8 contacts 0462-201-16141, and 6 sealing plugs 114017)																		
Installation	Mounting holes are sized for #10 or M5 bolts. The bolt length will be determined by the end-user's mounting plate thickness. The mounting flange of the controller is 0.47 in. (12 mm) thick. It should be mounted with connectors facing left or right to reduce likelihood of moisture entry. All field wiring should be suitable for the operating temperature range. Install the unit with appropriate space available for servicing and for adequate wire harness access (6 in. or 15 cm) and strain relief (12 in. or 30 cm).																		

## OUR PRODUCTS

AC/DC Power Supplies  
Actuator Controls/Interfaces  
Automotive Ethernet Interfaces  
Battery Chargers  
CAN Controls, Routers, Repeaters  
CAN/WiFi, CAN/Bluetooth, Routers  
Current/Voltage/PWM Converters  
DC/DC Power Converters  
Engine Temperature Scanners  
Ethernet/CAN Converters,  
Gateways, Switches  
Fan Drive Controllers  
Gateways, CAN/Modbus, RS-232  
Gyroscopes, Inclinometers  
Hydraulic Valve Controllers  
Inclinometers, Triaxial  
I/O Controls  
LVDT Signal Converters  
Machine Controls  
Modbus, RS-422, RS-485 Controls  
Motor Controls, Inverters  
Power Supplies, DC/DC, AC/DC  
PWM Signal Converters/Isolators  
Resolver Signal Conditioners  
Service Tools  
Signal Conditioners, Converters  
Strain Gauge CAN Controls  
Surge Suppressors

## OUR COMPANY

Axiomatic provides electronic machine control components to the off-highway, commercial vehicle, electric vehicle, power generator set, material handling, renewable energy and industrial OEM markets. ***We innovate with engineered and off-the-shelf machine controls that add value for our customers.***

## QUALITY DESIGN AND MANUFACTURING

We have an ISO9001:2015 registered design/manufacturing facility in Canada.

## WARRANTY, APPLICATION APPROVALS/LIMITATIONS

Axiomatic Technologies Corporation reserves the right to make corrections, modifications, enhancements, improvements, and other changes to its products and services at any time and to discontinue any product or service without notice. Customers should obtain the latest relevant information before placing orders and should verify that such information is current and complete. Users should satisfy themselves that the product is suitable for use in the intended application. All our products carry a limited warranty against defects in material and workmanship. Please refer to our Warranty, Application Approvals/Limitations and Return Materials Process at <https://www.axiomatic.com/service/>.

## COMPLIANCE

Product compliance details can be found in the product literature and/or on [axiomatic.com](http://axiomatic.com). Any inquiries should be sent to [sales@axiomatic.com](mailto:sales@axiomatic.com).

## SAFE USE

All products should be serviced by Axiomatic. Do not open the product and perform the service yourself.



This product can expose you to chemicals which are known in the State of California, USA to cause cancer and reproductive harm. For more information go to [www.P65Warnings.ca.gov](http://www.P65Warnings.ca.gov).

## SERVICE

All products to be returned to Axiomatic require a Return Materials Authorization Number (RMA#) from [rma@axiomatic.com](mailto:rma@axiomatic.com). Please provide the following information when requesting an RMA number:

- Serial number, part number
- Runtime hours, description of problem
- Wiring set up diagram, application and other comments as needed

## DISPOSAL

Axiomatic products are electronic waste. Please follow your local environmental waste and recycling laws, regulations and policies for safe disposal or recycling of electronic waste.

## CONTACTS

**Axiomatic Technologies Corporation**  
1445 Courtneypark Drive E.  
Mississauga, ON  
CANADA L5T 2E3  
TEL: +1 905 602 9270  
FAX: +1 905 602 9279  
[www.axiomatic.com](http://www.axiomatic.com)  
[sales@axiomatic.com](mailto:sales@axiomatic.com)

**Axiomatic Technologies Oy**  
Höytämöntie 6  
33880 Lempäälä  
FINLAND  
TEL: +358 103 375 750  
[www.axiomatic.com](http://www.axiomatic.com)  
[salesfinland@axiomatic.com](mailto:salesfinland@axiomatic.com)